

SPARE PARTS ORDERING INFORMATION

Insurance or breakdown spares can be obtained locally or from Delta Scientific Corporation as desired. If parts are found locally, they should be of the same manufacture and pattern as the original part. On hydraulic systems, we do not recommend the replacement of the main directional valve by any other manufacturer than Vickers/Double A or Rexroth.

Please specify the model number of the Barriers and the serial number when ordering parts from the factory. If these are not known, the original order number and date of purchase of the system should be given.

(Serial numbers are located on the equipment nameplates on the HPU and in the Barrier access area. The Model number of the system is also shown on the nameplate. Electrical control panels and circuits reference the appropriate drawing number; please provide this number when ordering control components.)

Use the numbers on the attached spare parts list as well as the actual component's manufacturers' number. Give as complete a description of the part and its function as possible. If uncertain as to the parts name or function, digital photos of the part(s) can be emailed for identification or a sketch can be mailed or faxed with the order.

On requests for accumulators, parts and service, confirm accumulator manufacturer, manufacturer's part number and serial number before ordering accumulators, service manuals and/or seal kits.

Motor starters as supplied by Delta consist of a starter contactor paired with starter overload. These two components snap together to form the motor starter. Over the years, various manufacturers have been used, and even starters of the same manufacturer have sometimes had their design series changed. So unless the system is relatively recent, we recommend that both the starter and overload be replaced as a unit so that the assembly is compatible.

Most parts are maintained in stock and can be processed for shipment within one week of order. If parts are for breakdown replacement, please note on order so that we may expedite shipment. If parts are not in stock, we will confirm your order with an expected delivery date.

Prices shown are net each, FOB Palmdale, California. Prices are subject to change without notice.

Contact:

Delta Scientific Corporation

40355 Delta Lane
Palmdale, California 93551
Phone (661)575-1100
Fax (661)575-1109
E-MAIL info@deltascientific.com